

SMARC T335X Linux Development

GPIO device busy error:

We are having trouble accessing the GPIO on the SMARC carrier board from the kernel v3.2. Are they somehow disabled?

**# echo 7 > /sys/class/gpio/export
that gives me the device busy error.**

To use GPIOs, you can either configure them in kernel or user space. Both way cannot be applied at the same time.

We configure the GPIO in our kernel and that's why you saw the device is busy because the kernel is in use.

If you would like to use them in user space. You need to comment out those line in arch/arm/mach-omap2/board-am335xevm.c

```
#define SMARC_GPIO0 GPIO_TO_PIN(3, 4)
#define SMARC_GPIO1 GPIO_TO_PIN(2, 5)
#define SMARC_GPIO2 GPIO_TO_PIN(1, 25)
#define SMARC_GPIO3 GPIO_TO_PIN(1, 24)
#define SMARC_GPIO4 GPIO_TO_PIN(2, 4)
#define SMARC_GPIO5 GPIO_TO_PIN(2, 3)
#define SMARC_GPIO6 GPIO_TO_PIN(1, 28)
#define SMARC_GPIO7 GPIO_TO_PIN(1, 29)
#define SMARC_GPIO8 GPIO_TO_PIN(2, 0)
#define SMARC_GPIO9 GPIO_TO_PIN(2, 1)
#define SMARC_GPIO10 GPIO_TO_PIN(3, 7)
#define SMARC_GPIO11 GPIO_TO_PIN(3, 8)
/* pin 37 of P1 in SBC-SMART-MEN */
#define SMARC_GPIO12 GPIO_TO_PIN(0, 15)
/* pin 38 of P1 in SBC-SMART-MEN */
#define SMARC_GPIO13 GPIO_TO_PIN(0, 14)
```

SMARC T335X Linux Development

```
/*  
  
* setup SMARC GPIO  
  
* GPIO0-GPIO5 is recommended for use as output and GPIO6-GPIO11 as inputs by  
  
* SMARC specification  
  
*/  
  
static void gpio_init(int evm_id, int profile)  
{  
  
    setup_pin_mux(gpio_pin_mux);  
  
/* GPIO0-GPIO11 */  
  
/* GPIO0*/  
  
    gpio_request(SMARC_GPIO0, "GPIO0");  
  
    gpio_direction_output(SMARC_GPIO0, 0);  
  
/* GPIO1*/  
  
    gpio_request(SMARC_GPIO1, "GPIO1");  
  
    gpio_direction_output(SMARC_GPIO1, 0);  
  
/* GPIO2*/  
  
    gpio_request(SMARC_GPIO2, "GPIO2");  
  
    gpio_direction_output(SMARC_GPIO2, 0);  
  
/* GPIO3*/  
  
    gpio_request(SMARC_GPIO3, "GPIO3");  
  
    gpio_direction_output(SMARC_GPIO3, 0);  
  
/* GPIO4*/  
  
    gpio_request(SMARC_GPIO4, "GPIO4");  
  
    gpio_direction_output(SMARC_GPIO4, 0);  
  
/* GPIO5*/
```

SMARC T335X Linux Development

```
gpio_request(SMARC_GPIO5, "GPIO5");

gpio_direction_output(SMARC_GPIO5, 0);

/* GPIO6*/

gpio_request(SMARC_GPIO6, "GPIO6");

gpio_direction_input(SMARC_GPIO6);

/* GPIO7*/

gpio_request(SMARC_GPIO7, "GPIO7");

gpio_direction_input(SMARC_GPIO7);

/* GPIO8*/

/* GPIO9*/

gpio_request(SMARC_GPIO9, "GPIO9");

gpio_direction_input(SMARC_GPIO9);

/* GPIO10*/

gpio_request(SMARC_GPIO10, "GPIO10");

gpio_direction_input(SMARC_GPIO10);

/* GPIO11*/

gpio_request(SMARC_GPIO11, "GPIO11");

gpio_direction_input(SMARC_GPIO11);

return;

}
```

If you release those lines from kernel. You are free to use GPIOs under user space.

Unique solution ID: #1009

Author: Eric Lee

Last update: 2014-08-16 18:13